


Engraved Wall Panel Installation Instructions

For specific advice on installation contact Boyd. This advice is designed to assist experienced installers in standard applications.



Before Installation

Slight colour variations can be present between batches of acoustic material. Please check that your product order does not show any colour variation before installation. Ensure that the Boyd Acoustic Panels are not bent during storage or prior to installation as this can cause creases. Also ensure that edges of the panel are protected from damage. A clean environment and clean hands are essential to ensure panels are not marked.

Adhesive

We recommend a contact adhesive, sprayed on to the back of the panel and the substrate.

Cutting

Cutting of Boyd Acoustic Panels can be done with a slide cutter, craft knife or circular saw.

Installation

Ensure hands are clean or gloves are worn, particularly when installing light coloured panels. Boyd Acoustic Panels should be applied to flat wall substrates. Install each panel separately. Apply adhesive to both the panel and substrate ensuring all areas are masked off to prevent over spray. Once the adhesive is tacky, fit the Boyd Acoustic Panel to the wall starting with any joins first. Smooth the entire surface from the centre outwards to ensure a good adhesive bond. Press firmly on to the substrate.

Substrate

Boyd Acoustic Panels can be applied to a wide range of surfaces. A level 3 finish is recommended. Surfaces should be clean, free of dust and dry. Boyd Acoustic Panels can be applied over small gaps in substrate but it is recommended that any gaps are sealed with tape before installation. Gloss finishes should be sanded prior to application.